



ROLLER SHADES WITH CASSETTE INSTALLATION INSTRUCTIONS

HEAVY DUTY CLUTCH OPERATED SYSTEM WITH CASSETTE

1. MOUNT THE BRACKETS

Outside mount: Install above the wood trim or window frame. Use the rear bracket holes.

Inside mount: Install inside the window frame. Use the top bracket holes. Install the two outside brackets first, no further than 2" in from each end of the headrail. Install the remaining brackets evenly spaced in increments of 24" or less. Care should be taken to ensure all brackets are level.

2. MOUNT THE SHADE

Place the top middle lip of the headrail on the top lip of all brackets. Push the bottom front of the headrail firmly backwards until the headrail snaps into place. Installation is complete.

3. INSTALL THE TENSION DEVICE

It is essential to use this device to reduce the hazards of strangulation and entanglement of young children by limiting access to the bead chain. Place the device on the wall, insert & secure the two screws through holes in it. Mounting screws must be secured into a solid surface.

4. USE THE BEAD CHAIN TO OPERATE THE SHADE.

Pulling gently on the cord in one direction raises the shade; pulling it in the other direction lowers it.

5. ATTACH STOPS TO A CONTROL CORD THAT'S MADE OF BEAD CHAIN

On metal bead chain, attach a metal stop ball that is at least 5/16" (8mm) in diameter, so that it touches the clutch when the shade is in the fully raised position. For metal or plastic bead chain, lower the shade to its fully lowered position, and attach the appropriate metal stop or plastic stop so that it touches the clutch. This prevents the shade from being lowered beyond that point.

6. TO ADJUST ROLL-UP (IF NECESSARY):

IMPORTANT: At first, make sure brackets are mounted level.

Case 1: If shade cloth veers toward right: Lower the shade completely and place a piece of tape (multiple pieces may be necessary - max 4 layers) close to the left edge of the roller.

Case 2: If shade cloth veers toward left: correct by following the same steps as case 1, except that the tape must be placed at the right edge of the roller.

