



Vertical Blind Installation Instructions

Please follow these Installation Instructions


You will need a pencil, tape measure, drill, screwdriver, pliers, and appropriate fasteners.

Step 1: Choose the Correct Fastener



Step 2: Bracket Installation *(Before installing, review the chart below to confirm the correct # of brackets per blind)*


Outside Mount (Figure A)



Standard wall mount installation brackets are adjustable and provide 1/2" to 1 1/2" wall clearance. Determine the height for the top of the bracket (measured from the floor) by adding 1/2" to the blind height including the headrail. When installed, louvers will clear the floor by 1/2".


Place the first bracket directly over the corner of the window with maximum space of 30" between brackets. Adjust the bracket so the louver clear all obstructions.

Inside Mount (Figure B or C)



Use mounting clips to secure headrail on ceiling or inside mounts. The center of the mounting clips align with the center of the louver carrier stem. Position the screws a minimum of 2 1/4" in front of the window frame or any projection.

Set mounting clips with a maximum space of 30" apart from each other. Allow a minimum of 1/2" clearance above sill or carpet.




Use the following # of Installation Brackets based on the Blind Width:

Up to 38"	38 1/8" - 68"	68 1/8" - 98"	98 1/8" - 128"	128 1/8" - 158"	158 1/8" - 188"	188 1/8" - 218"	218 1/8" - 40"
2	3	4	5	6	7	8	9


Step 3: Headrail Installation

Mount the installation brackets on the headrail then snap in place, as shown below. To remove headrail, simply push the release lip up with a screwdriver.




Step 4: Louver Installation

Push the louver up into the carrier stem, then pull slightly straight down to lock in place.




Vertical Blind Installation Instructions

Step 5: Test Rotation



Pull the bead chain once in each direction, rotating the louvers from front to back. This step will align all of the louvers.

Step 6: Test Traverse



Alternatively pull the nylon cords to ensure that the blind traverses smoothly in both directions.

Caution: Do not traverse the blind with the louvers in the closed position.

Valance Installation




For inside or ceiling mounts, install the headrail bracket clip mounting screw through the valance as shown. Make sure louvers do not touch the valance. **Note:** No valance clips are needed for Inside Mount Installation.

For outside mounts, a plastic valance clip is provided. Snap the valance clips onto the aluminum headrail. Then, slide the top dust cover of the valance into the plastic valance clips until they lock in place.

Before installing, review the chart below to confirm the correct # of valance clips per blind.

Valance Returns

Valances are available with Square Snap in Corner Returns or Round Corner Returns. Returns for Round Corner Valances will come pre-assembled. For Square Corner Valance Returns, slide the clear plastic corner clip onto the top edge of the valance. Then, slide the valance return into the other side of the corner clip as shown. Valance returns may be trimmed to fit if necessary with heavy duty scissors.



Use the following # of Installation Brackets based on the Blind Width:

Up to 38"	38 1/8" - 68"	68 1/8" - 98"	98 1/8" - 128"	128 1/8" - 158"	158 1/8" - 188"	188 1/8" - 218"	218 1/8" - 40"
2	3	4	5	6	7	8	9

Operating Instructions

Cord & Chain Control

To rotate the louvers, gently pull the bead chain. To traverse the louvers, gently pull on the nylon cord. For proper traversing of the louvers, it is critical that the louvers be rotated to the open position prior to pulling on the cord to draw the louvers across the window opening.

If louvers become tangled or have moved out of alignment with use, re-adjustment is simple. With your hand, gently adjust the louvers so they are all facing the same direction. Make certain that the louvers are overlapping each other in the correct direction. Pull the bead chain until you hear a grinding sound. Give the chain an additional gentle pull. This grinding sound comes from the louver

carriers re-aligning themselves. Now, pull the chain in the opposite direction and all of the vanes will be aligned correctly.

Wand Control

To rotate the louvers, rotate the wand in the direction you want the louvers rotated. To traverse the louvers, rotate the louvers to the open position. Then, push or pull the wand to open (stack louvers) or close (unstack louvers) the blind. If the louvers are installed with the front of the louver facing the wand, the wand will be in front of the louvers when the blind is rotated closed. If the louvers are installed with the back of the louver facing the wand, the wand will be in back of the louvers when the blind is rotated closed.